



Sensorform earth fault indicators



suparule

Various models and options
to choose from:

- IP65 rating
- Indication method: Mechanical Flag/LED
- Resetting method: Auto-reset/Timer-reset/Manual-reset
- Power source option: Mains/Battery /CT powered
- Automation option: Aux. Relay/Remote LED indicator
- Trip Level: Factory set/user selectable



Robust, Reliable Earth Fault Indicators | VALUE FOR MONEY

Contact Sales: sales@suparule.com