



suparule



Sensorform **EFI-MFZ-50** Earth Fault Indicator with Mechanical Flag

- Powered from mains supply 110V-240V AC
- Mechanical flag primary indicator
- Automatic reset of fault state when mains power is restored
- Manual reset of fault flag by Test/Reset button on front panel
- LED based Remote indicator (optional)
- Aux Relay contact for remote alarm generation (optional)

DESCRIPTION

Sensorform EFI-MFZ-50 is one of a family of Earth Fault Indicator products that are designed to assist in the rapid location and isolation of faults on high voltage networks (1-36kV) in single-sided feed or open ring main systems. When an asymmetrical current greater than 50A in a 3 phase cable is detected an earth fault is indicated by means of a mechanical flag indicator.

A current sensor is fitted around the three phases of the cable system being monitored and detects a current imbalance due to an earth fault. An earth fault trip is indicated by a mechanical Flag Indicator and LED based Remote Indicator (fitted as optional). An auxiliary relay contact is also provided as an optional extra for signaling an alarm to other systems. In an open ring network the path of the fault current from the feeding point to the fault location is marked by the triggered EFI's. The defective conductor segment is located between the last EFI that has been triggered and the first EFI which is still inactive.

FEATURES

- Powered from mains supply 110-240V AC
- Mechanical flag primary indicator
- Automatic reset of fault state when mains power is restored
- Manual reset of fault flag by Test/Reset button on the front panel
- CT100 Current Sensor (standard)
- CT150 Current Sensor (optional)
- CT300 Current Sensor (optional)
- Aux Relay contact for remote alarm generation (optional)
- Rugged design suitable for outdoor use
- ISO9001:2000 based Quality Assurance

Distributor:

SPECIFICATIONS

General

Power Source:	Mains Supply 110-240V AC +/-20% 50-60Hz
Network Volt. Range:	1-36kV
Impulse Voltage Withstand:	10kV, 1.2/50µS waveform
Trip Current:	50A ±10%
Primary Indication:	Mechanical Flag (RED)
Min. Fault Duration:	2.5 cycles
Manual Reset:	Push button on front panel
Automatic Reset Period:	10 Seconds after mains restore
Manual Trip Test:	Manual Push Button
Operating Temperature Range:	-40° C to +80° C
Operating Humidity Range:	0-100% RH
Dimensions:	115mm x 65mm x 40mm
Degree of Protection:	IP65
Mass:	250g
Current Sensor Diameter:	Standard CT100: 100mm Optional CT150: 150mm Optional CT300: 300mm
Remote Indicator (optional)	
Indication Method:	Flashing LED @ 1 Hz
Flashing Duration:	10 hours nominal
Dimensions:	M12 Hex Bolt 50mm long
Auxiliary Relay (optional)	
Type:	Latching, N/O on reset
Rating:	220VDC, 250VAC, 2A
Lead type:	2-core, 0.5mm ² double Insulated

Warranty Period

2 Years

Suparule Systems Ltd.,
Suparule House,
Lonsdale Road,
National Technology Park,
Limerick, Ireland.

Ph.: +353 (0) 61 201030
Fax.: +353 (0) 61 330812
Email: info@suparule.com
Web: www.suparule.com